








We want assembly to be easy, so please feel free to contact us if you have any questions: 812-876-0677

Here's what's in the packages

Your parts may look a little different from these, depending on the table you ordered.

Table Top Halves and Leaf		Slide Carriage		
Leg Units		OR	Base	
Carriage Bolts		Leg/Base Bolts		

Hex key	OR	
---------	----	--

Overview of the steps:

1. Attach the slide carriage to the table top halves.
2. Attach the leg plates to the slide carriage.
3. Turn the table over and check alignment.
4. Adjust the alignment if necessary.

Step by step instructions:

- 1A) Place table top halves upside-down and pushed together on a blanket or other soft surface.
- 1B) Set the slide carriage in place on the table top halves.
- 1C) Attach the carriage to the top halves using the carriage screws. Lightly tighten all of these bolts.



- 2) Attach the leg plates to the slide carriage using the leg screws. Fully tighten all of these bolts.



For this section, please watch our assembly video at:

<https://youtu.be/yBmylHPviWE>

3. Turn the table over and check alignment.

- Carefully flip the table right-side-up onto the floor. Two people are needed for this step.
- Open the table top halves by pulling them apart, extending the slides.
- Insert the table leaf and GENTLY close the table by pushing the outer halves together.
- Check the alignment of the pins in the edge of the table top sections. If the pins do not align with their corresponding holes, proceed to step 9. If they do align assembly is finished.

4. If table pins do not align, adjust the slide carriage:

- Loosen the **carriage bolts** (not the leg bolts) underneath the table top.
- Push the table sections and leaf together fully, gently jiggling them sideways if necessary to align the pins.
- Once the table top sections are aligned and fully together, tighten the carriage bolts.
- Assembly is finished.